

Laser Pointer

LASER POINTER



MODEL	DESCRIPTION	ORDER NUMBER
SG-LP	Laser pointer	95ASE5590
COMPATIBILITY		
All SG Series Safety Light Curtains except SG4-H and SLIM		

Communication interface

DONGLE



MODEL	DESCRIPTION	ORDER NUMBER
SG4-DONGLE	Ethernet adaptor	95ASE2080
FUNCTIONS		
1) Ethernet connection (TCP/IP) to Monitoring and Configuration Software SG4-E GUI. 2) Configuration cloning 3) Error logging 4) Configuration logging		
COMPATIBILITY		
SG4 EXTENDED		

NOTE

To connect SG-DONGLE directly to a PC, order Ethernet cable CAB-ETH-M01