


Accessories


PSEN ml/cs Y junction M12/PSEN ml end adapter

Connection



Legend

	Order no. 570486	Order no. 570489	Order no. 570487
X1	M12 male connector	M12 female connector	M12 female connector
X2	M12 female connector	M12 male connector	M12 male connector
X3	M12 female connector	M12 female connector	-



Legend

	Order no. 570486	Order no. 570489
X1	M12 male connector	M12 female connector
X2	M12 female connector	M12 male connector
X3	M12 female connector	M12 female connector

PSEN ml/cs Y junction M12/PSEN ml end adapter



INFORMATION

If you want to use Safety Device Diagnostics, one of the listed adapters must be used instead of PSEN ml / PSENcs Y junction M12 (order no. 570489):


- PSEN Y junction M12 SENSOR (order no. 540315)
- PSEN Y junction M12 cable channel (order no. 540316)
- PSEN Y junction M12 SENSOR (order no. 540337)
- PSEN Y junction M12-M12/M12 PIGTAIL (order no. 540338)

Which adapter to use will depend on the relevant PSENcode.


PSEN ml/cs Y junction M12/PSEN ml end adapter

Connector pin assignment


- ▶ PSEN ml Y junction M12, order no. 570 486
Adapter for series connection of PSEN ml




Plan view of plug-in connector X1



Plan view of plug-in connector X2



Plan view of plug-in connector X3



Contact assignment