

ZSB077040 (Order no. 077040)

ZSB, housing G1, 3-stage, +/- buttons, cable with plug connector RC12

- ▶ Housing G1
- ▶ 3-stage function
- ▶ Straight connecting cable, 5 m
- ▶ Plug connector
- ▶ 2 pushbuttons



Switching element

2220 2 NO/NC 


3-stage function

Enabling function is active only in the second stage (center position, actuating point). If the pushbutton is released or pushed further (panic function), the enabling is removed (dependent on the wiring, see function sequence).


+ and - buttons

These pushbuttons can be configured individually. For example, for moving axes in positive or negative direction.

Dimensional drawings



Polbild / Mating face
Ansicht Steckseite / View of connection side
2:1



Dimensional drawings

