

ZSM4200-124156 (Order no. 124156)

ZSM, pushbuttons

- ▶ 3-stage function
- ▶ Pushbuttons
- ▶ Coiled connecting cable, 5 m



3-stage function

Enabling function is active only in the second stage (center position, actuating point). If the pushbutton is released or pushed further (panic function), the enabling is removed (dependent on the wiring, see function sequence).

Pushbuttons

Additional functions can be run directly at the enabling switch using the pushbuttons.

Cable

The high-quality connecting cables are available in a coiled version.