

## ZSA2A4G05C-C2041 (Order no. 092738)

### ZSA, 3-stage, with cable and plug connector RC17

- ▶ Housing G1
- ▶ 3-stage function
- ▶ Straight connecting cable with plug connector, 5 m




### Switching element

2220 2 NO/NC (→)



### 3-stage function

Enabling function is active only in the second stage (center position, actuating point). If the pushbutton is released or pushed further (panic function), the enabling is removed (dependent on the wiring, see function sequence).

### Dimensional drawings



**Dimensional drawings**



Connection examples

