PowerScan 9501-DPM Series	
PowerScan D9531 Direct Part Marking Evo	PD9531-DPM
PowerScan D9531, Direct Part Marking Evo, RS-232 Kit (Kit inc. Scanner and Cable CAB-434.)	PD9531-DPMK2
PowerScan D9531, Direct Part Marking Evo, USB Kit (Kit inc. Scanner and Cable CAB-550.)	PD9531-DPMK1
PowerScan PBT9501, Bluetooth, Direct Part Marking EVO, Removable Battery	PBT9501-DPMRB
PowerScan PBT9501, Direct Part Marking Evo, RS-232 Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-BT, Cable CAB-433, Power Brick 8-0935 and Power Cord 6003-0941.)	PBT9501-DPMRBK20US
PowerScan PBT9501, Direct Part Marking Evo, RS-232 Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-BT, Cable CAB-433, Power Brick 8-0935 and Power Cord 6003-0940.)	PBT9501-DPMRBK20EU
PowerScan PBT9501, Direct Part Marking Evo, USB Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-BT, Cable CAB-438, Power Brick 8-0935 and Power Cord 6003-0940)	PBT9501-DPMRBK10EU
PowerScan PBT9501, Direct Part Marking Evo, USB Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-BT, Cable CAB-438, Power Brick 8-0935 and Power Cord 6003-0941)	PBT9501-DPMRBK10US
PowerScan PM9501, 433 MHz, Direct Part Marking Evo, 4-Key Display, Removable Battery	PM9501-DDPM433RB
PowerScan PM9501, 433 MHz, Direct Part Marking Evo, Ethernet Kit, Removable Battery (Kit inc. Scanner, Base Station BC9180-433, Power Brick 8-0935 and Power Cord 6003-0940.)	PM9501-DPM433RBK30
PowerScan PM9501, 433 MHz, Direct Part Marking Evo, Removable Battery	PM9501-DPM433RB
PowerScan PM9501, 433 MHz, Direct Part Marking Evo, RS-232 Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-433, Cable CAB-433, Power Brick 8-0935 and Power Cord 6003-0940.)	PM9501-DPM433RBK20
PowerScan PM9501, 433 MHz, Direct Part Marking Evo, USB Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-433, Cable CAB-438, Power Brick 8-0935 and Power Cord 6003-0940.)	PM9501-DPM433RBK10
PowerScan PM9501, 910 MHz, Direct Part Marking Evo, 4-Key Display, Removable Battery	PM9501-DDPM910RB
PowerScan PM9501, 910 MHz, Direct Part Marking Evo, Ethernet Kit, Removable Battery (Kit inc. Scanner, Base Station BC9180-910, Power Brick 8-0935 and Power Cord 6003-0941.)	PM9501-DPM910RBK30
PowerScan PM9501, 910 MHz, Direct Part Marking Evo, Removable Battery	PM9501-DPM910RB
PowerScan PM9501, 910 MHz, Direct Part Marking Evo, RS-232 Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-910, Cable CAB-433, Power Brick 8-0935 and Power Cord 6003-0941.)	PM9501-DPM910RBK20
PowerScan PM9501, 910 MHz, Direct Part Marking Evo, USB Kit, Removable Battery (Kit inc. Scanner, Base Station BC9030-910, Cable CAB-438, Power Brick 8-0935 and Power Cord 6003-0941.)	PM9501-DPM910RBK10

BASE STATION	
BC9030 Base Presentation Charger, 433MHz, Multi-Interface (RS-232, USB and KBW), Black	BC9030-BK-433-BP
BC9030 Base Presentation Charger, 433MHz, Multi-Interface (RS-232, USB and KBW), White	BC9030-WH-433-BP
BC9030 Base Presentation Charger, 910MHz, Multi-Interface (RS-232, USB and KBW), Black	BC9030-BK-910-BP
BC9030 Base Presentation Charger, 910MHz, Multi-Interface (RS-232, USB and KBW), White	BC9030-WH-910-BP
BC9030 Base Presentation Charger, BT, Multi-Interface (RS-232, USB and KBW), Black	BC9030-BK-BT-BP
BC9030 Base Presentation Charger, BT, Multi-Interface (RS-232, USB and KBW), White	BC9030-WH-BT-BP
BC9030 Base Station/Charger, 433 MHz, Multi-Interface (RS-232, USB and KBD Wedge)	BC9030-433
BC9030 Base Station/Charger, 910 MHz, Multi-Interface (RS-232, USB and KBD Wedge)	BC9030-910
BC9030 Base/Charger BT Multi-Interface (RS-232, USB and KBW)	BC9030-BT
BC9130 Base Station/ Dual Charger, 433 MHz, Multi-Interface (RS-232, USB and KBD Wedge), Spare Battery Slot	BC9130-433
BC9130 Base Station/ Dual Charger, 910 MHz, Multi-Interface (RS-232, USB and KBD Wedge), Spare Battery Slot	BC9130-910
BC9130 Base/Dual Charger BT Multi-Interface (RS-232, USB and KBW), Spare Battery Slot	BC9130-BT
BC9160 Base Station/Dual Charger, 433 MHz, Multi-Interface (RS-232, USB, KBD Wedge and RS485), Spare Battery Slot	BC9160-433
BC9160 Base Station/Dual Charger, 910 MHz, Multi-Interface (RS-232, USB, KBD Wedge and RS485), Spare Battery Slot	BC9160-910
BC9180 Base Station/Dual Charger, 433 MHz, Ethernet	BC9180-433
BC9180 Base Station/Dual Charger, 910 MHz, Ethernet	BC9180-910
BC9180 Base/Dual Charger BT Ethernet, Spare Battery Slot	BC9180-BT

EASEOFCARE AGREEMENTS	
FIELDBUS CONV, EoC, 2 DAYS COMP, 5 YEARS	ZSC2FBUSC51
MINIMUM REPAIR CHARGE,PBT95XX DPM	ZR0PM95DPMMIN
MINIMUM REPAIR CHARGE,PD95XX DPM	ZR0PD95DPMMIN
PD95XXDPM EofC 2 Days Comprehensive, 1 Year Renewal	ZSC2PD95DPMR1
PD95XXDPM EofC 2 Days Comprehensive, 3 Year	ZSC2PD95DPM31
PD95XXDPM EofC 2 Days Comprehensive, 5 Year	ZSC2PD95DPM51
PD95XXDPM EofC 5 Days, 1 Year Renewal	ZSN5PD95DPM5R1
PD95XXDPM EofC 5 Days, 3 Year	ZSN5PD95DPM31