

## RECESSED LIGHTING

## **EDGE LED LIGHT PANEL**

EDGE-12-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

## **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT CONDUCTOR SUITABLE FOR 90°C PERMITTED IN BOX (2 WIRES IN AND 2 WIRES OUT).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT CONDUCTOR SUITABLE FOR 90°C PERMITTED IN BOX (3 WIRES IN AND 3 WIRES OUT).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- 8. Use the selector tab on the side of the driver/junction box to select color temperature (preset at 3500 K) [Fig. 3].
- Secure driver to structure using the attached mounting plate.


## **INSTALLATION INSTRUCTIONS:**


- Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- 7. Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736

LITELINE.COM